

CHAPTER 35

FLUSHING SYSTEM (PLATE XIII)

35-1

The Flushing System consists of a single branch taken from firemain in the engine room B-1 which serves the officer's W.R. and W.C. A-103-1/2L and the crew's W.C. space A-103L.

The flushing line is fitted with main and by-pass cut-out valves, a reducing valve set to reduce the pressure in the flushing system to 35 p.s.i., a pressure gauge and relief valve. The relief valve is set to relieve pressure at 45 p.s.i. These valves are located in the engine room B-1 on the starboard side.

The cut-out valve for this system outside of the machinery space is located in the General Stores compartment A-211-5AC.

For further information concerning the Flushing System, see PLATE XIII.